



CUP  
HOLDERS

AK-8




SEAT

AK-9




WATER  
TEMP


AK-10




AK-xx



AK-xx



AK-xx



AK-xx



IGNITION

OFF


AL-1



IGNITION

OFF

AL-2



IGNITION

ENGINE

OFF

AL-3



START

IGNITION

OFF

AL-4



START

PORT  
IGNITION

OFF

AL-5




START


STBD  
IGNITION

OFF


AL-6




AL-x




AL-x




AL-x




AL-xx




AL-xx




AL-xx



AL-xx



AL-xx



ON

ANCHOR

OFF

AM-1




AFT

FUEL

FWD

AM-2




ON


AUX

OFF


AM-3




AM-x








AM-x



AM-x




AM-x





CU-1



CU-2



CU-3



CU-4



CU-5



CU-6



CU-7



CU-8

